WarmlyYours
Radiant Heating Systems
Experts since 1999

WIRING DIAGRAM

For 120V & 240V Slab Heating Products with
nSpire Touch Wi-Fi (UWG4), nSpire Touch (UDG4),
nHance (UDG), nTrust (UTN4), nJoin (USG)
nJoy (UWG5)





1. MAT/CABLE HAS NO POLARITY
2. DO NOT CUT THE HEATING WIRE
3. ALWAYS TEST OHMS OF HEATING PRODUCT BEFORE, DURING AND AFTER INSTALLATION
4. ALWAYS TEST SENSOR AND VERIFY 8-15 K OHM RESISTANCE
5. NEVER INSTALL ELECTRIC FLOOR HEATING UNDER PERMANENT FIXTURES
6. THE INSTALLATION MUST COMPLY WITH ALL NATIONAL AND LOCAL ELECTRICAL AND BUILDING CODES, INCLUDING AUTHORITY HAVING JURISDICTION.

c UL us LISTED

WarmlyYours
Radiant Heating Systems
Experts since 1999

WIRING DIAGRAM

For 120V & 240V Slab Heating Products with Relay Panel and Floor Heating Thermostat